GE Straight AC

CAUTION!
SHOCK HAZARD!
Disconnect power supply before servicing any electrical component.

ICM CONTROLS
Soft starter

Legend:
S = Start
C = Common
H = Hermatic
R = Run
OL = Overload Switch
F = Fan
(Disconnected)

Terminal Block

L1

Red
Blue
Brown
Black

Start Capacitor

PTCR

③

White

Red

White

L2

Run Capacitor

F

C

H

③

②

④

⑤

3-way Spliced

Black

Black

Spliced

①

White

OL

C

R

S

Red

Compressor